



A Teledyne Technologies Company 9480 Carroll Park Drive, San Diego, CA 92121-2251 Phone (858) 657-9800 Fax: (858) 657-9818 Toll Free 1800 324-5190 E-mail: api-customerservice@teledyne.com http://www.teledyne-api.com

> 01-029C 2 May, 2007

INSTALLING OZONE FILTER ON M200A/M201A/M200AH ANALYZERS

I. <u>PURPOSE</u>:

To provide instructions when installing the ozone filter on the M200A/M201A/M200AH Teledyne API NO_xanalyzers.

- II. <u>TOOLS</u>: 7/16" open end wrench
 - 1/2 " open end wrench
- III. <u>PARTS</u>:

KIT000081

IV. <u>PROCEDURE</u>:

- a. Remove power to the analyzer and pump pack.
- b. Remove the cover
- c. Remove fitting on top of the RxCell that goes from the ozone generator to the RxCell.
- d. Connect the 1/8" tube that comes from the ozone generator to the bottom of the ozone filter.
- e. Connect the 1/8" SS tube that is in the kit to the fitting on top of the RxCell that the ozone goes into.
- f. Leak check the unit.
- g. Put the cover back on to the unit and start the unit back up.
- h. Do the regular calibration of the unit.