



M465L Troubleshooting Tree Page 1 of 9

UNSTABLE READING AT ZERO, ZERO NOISE




M465L Troubleshooting Tree Page 2 of 9


UNSTABLE READING AT SPAN, SPAN NOISE



M465L Troubleshooting Tree Page 3 of 9



M465L Troubleshooting Tree Page 4 of 9





M465L Troubleshooting Tree Page 5 of 9

SLOW RESPONSE TO ZERO OR SPAN




M465L Troubleshooting Tree Page 6 of 9







M465L Troubleshooting Tree Page 7 of 9



SENSOR OK LIGHT IS OFF



M465L Troubleshooting Tree Page 8 of 9



M465L Troubleshooting Tree Page 9 of 9