



# TELEDYNE INSTRUMENTS

*Advanced Pollution Instrumentation*

A Teledyne Technologies Company  
9480 Carroll Park Drive, San Diego, CA 92121-5201  
Phone (858) 657-9800 Fax: (858) 657-9818 Toll Free 1800 324-5190  
E-mail: [api-customerservice@teledyne.com](mailto:api-customerservice@teledyne.com) <http://www.teledyne-api.com>

## Service Note

98-054 Rev B  
2 May, 2007

### OZONE ANALYZER PUMP

I. **SCOPE:**

To inform our customers of a potential hazard in the Model 400/450 analyzers.

II. **PARTS:**

KIT 000066

III. **TOOLS:**

None

IV. **PROCEDURE:**

There is a potential rotating equipment hazard in the M400 & M450 if you pull down the front panel & reach your hand into the analyzer. If you have to reach into an analyzer, remove the cover from the analyzer & be careful not to touch the cooling fan on the sample pump. We do not advise that you ever stick your hand into the analyzer through the front panel without first removing the cover from the analyzer.

Analyzers built after August of 1998, come equipped with a shield that prevents you from being able to reach around the printed circuit cards and potentially injuring yourself. If you would like to purchase one of these shields, the part number is: KIT 000066.

If you have questions regarding this procedure or any API equipment, please contact an API Customer Service representative at:

Phone: (619) 657-9800

Fax: (619) 657-9816

Email: [customerservice@advpol.com](mailto:customerservice@advpol.com)