



**99-045 Rev B  
2 May, 2007**

**OPTIC TEST POT REPLACEMENT NOTIFICATION**

**I. SCOPE:**

To inform our customers of a change in the Optic Test Pot value on the pre-amp card on the M100A and M200A analyzers.

**II. PARTS:**

NONE

**III. TOOLS:**

NONE

**IV. INFORMATION:**

1. We have changed the value of the OT pot on the pre-amp cards for the M100A and M200A analyzers.
2. This change will ensure that no matter what value you have the HVPS set to that you will be able to adjust the OT pot so that you can get the pmt value that you are looking for on the front panel of the instrument. If you would like to change the pot on an existing pre-amp card to make the same modification that is not a problem. The pot that we changed was R25 on the 02107 card. This pot was changed from a 10K pot to a 50K pot.
3. Please keep in mind that OT is still a go no-go test and that this is not intended as a stability check or linearity check.

If you have questions regarding this procedure or any API equipment, please contact an API Customer Service representative at:

OPTIC TEST POT REPLACEMENT NOTIFICATION

**99-045-A**

Page 1 of 2

Phone: (858) 657-9800  
Fax: (858) 657-9816

Email: [customerservice@advpol.com](mailto:customerservice@advpol.com)  
WWW: <http://www.advpol.com>