

Service Note

A Teledyne Technologies Company 9480 Carroll Park Drive, San Diego, CA 92121-5201 Phone (858) 657-9800 Fax: (858) 657-9818 Toll Free 1800 324-5190 E-mail: <u>api-customerservice@teledyne.com</u> <u>http://www.teledyne-api.com</u>

> 98-009 Rev B 2 May, 2007

RETROFIT TO CAS SWITCH

I. <u>Scope</u>:

This service note addresses changing a crystal in the CAS switch. The retrofit should be done on any CAS switch that has a symptom of dropping characters during send or receive.

II. <u>Tools</u>:

- A. Solder sucker or other removal device
- B. Soldering equipment
- C. 5.000 MHz crystal
- D. #2 Phillips head screwdriver

III. <u>Procedure</u>:

- A. Remove the cover and power from the CAS switch. On older models, this means removing 4 screws and sliding off the cover. On newer models, there are slide bars locking the cover on. Slide them and lift the cover off.
- B. Locate the crystal. It is to the right of the mode switch, just inside the front panel.
- C. Remove the screws holding the PC card in the case.
- D. Lift the PC card out of the case and turn it over.
- E. Remove the crystal from the PC card.
- F. Install the new crystal into the PC card.
- G. Assemble in the reverse order of disassembly.